

Tools Required - None

Materials Required – Clean micro fiber cloths, car polish

Hardware Required/Included - None

Pre Installation

1. Carefully read and follow instructions to ensure optimal performance
2. Thoroughly wash & wax vehicle surfaces including inside wheel wells and under front bumper, to prevent entrapment of moisture and/or debris between paint finish and *SpeedLingerie*.
3. Place unfolded *SpeedLingerie* in direct sunlight, or near (but not in direct contact with) any radiant heat source for 20-30 minutes to warm-up the *SpeedLingerie*. Park the car in direct sunlight to warm-up the front-end surface. **NOTE!** Warming the *SpeedLingerie* and the vehicle front-end will make the *SpeedLingerie* more flexible and easier to install.
4. Orient yourself with *SpeedLingerie*. Notice placement correlation of mesh and grills.
5. For easier access to wheel well area, turn the steering wheel to the passenger side.

Hood Cover Installation

1. Slide the hood cover onto the hood.
2. Align the center hole on the underside with the hood latch loop.
3. Align the side holes on the underside with the rubber bumpers under the hood.
4. Attach the two (2) tension cords to openings on the underside of the hood towards the rear.
5. Align the emblem window on the topside of the Hood Cover with the Porsche emblem.
6. **NOTE!** Tuck/place the seam at the edge of the hood just **UNDER** the hood. This provides a seamless look, and sufficient clearance to close the hood properly.

SpeedLingerie™ Nose Cover Installation

1. Open the hood.
2. Face the front of the vehicle. Hold the properly oriented *SpeedLingerie* outstretched in front of you.
3. Tuck the headlight tab on the passenger side of the *SpeedLingerie*, under the headlight on the passenger side (if so equipped, align the hole in the *SpeedLingerie* with the headlight washer nozzle).
4. Repeat step#3 on the driver side.
5. Tuck the top edge of the *SpeedLingerie* into the top edge of the trunk. Lift the hood latch so it lays 'over' the *SpeedLingerie*. Lower the hood and adjust the *SpeedLingerie* edges, so the hood will close. Off-set the rear edge of the Hood Cover to be a little forward of the rear edge of the Nose Cover (at the hood edge near the headlight).
6. Using the palm of your hand, press on the center of the hood, then passenger side, then the driver side. Repeat these steps 3-4 times. Then using your palm, press the center of the hood on the badge area until you hear the hood latch click closed.
7. **NOTE:** If you cannot get the hood closed, don't worry. We know it is tight, but it will fit. Simply remove the Hood Cover and close the hood on the *SpeedLingerie* Nose Cover with out the Hood Cover installed. Leave the car parked in the garage for a few days, until the material has had a chance to become compacted at the edges. In a few days, repeat steps #6 & #7 and install the Hood Cover.
8. At the passenger side, run your thumb through the length of the *QuiKlip* (molded fastener strip) to "open it up" slightly. This will help you to clip the fastener on the wheel well edge. **NOTE!** Enfold (using a key or credit card or business card) the 5-inch quick release strap within the *QuiKlip* (molded fastener). This ensures easy removal of *SpeedLingerie*. Do not pull on this strap during installation.
9. At the passenger side, start just under the side marker. Clip the *QuiKlip* onto the wheel well lip and work your way down. Do not yet attach the top portion of the side *QuiKlip* (over the side marker).
10. **NOTE!** Due to the perfectly tailored fit of *SpeedLingerie*, step#7 takes careful effort. Acquire assistance, to provide "slack" from the front-end midpoint. Do not pull on the *QuiKlip* /stitching itself. Do not pull from the top edge. Installation becomes easier with repeated use.

SpeedLingerie™ Nose Cover Installation – continued

11. Working from the passenger side, come across the front end and carefully but firmly stretch the *SpeedLingerie™* towards the driver side. Gather 6-8" of material at the *QuiKlip™* in your hands, and carefully but firmly pull from the midpoint (side marker level) and the lower corner (spoiler level).
12. Repeat step #9 on the driver side.
13. Attach the top portion of the side *QuiKlip™* on the driver side. Simply 'flip' the flat tab under the lip edge of the wheel well just over the side marker. **NOTE!** You will have to gently pull slightly upward and towards the rear of the vehicle to flip-in this tab. Clip the *QuiKlip™* (s) at the bottom edge of the *SpeedLingerie™* to the bottom edge of the body.
14. Repeat step #13 on the passenger side.
15. Attach small bottom clips, at the lower side edges of the Nose Cover, to the wheel well edge, on both sides.
16. Attach the four underside clips, at the bottom of the Nose Cover, to the underside body edge, on both sides.

Mirror Cover Installation (optional)

1. To differentiate between passenger and driver side mirror cover, the vinyl covered loop portion of the hook & loop fastener folds **down and over** the hooked portion.
2. Lower/open windows. Close doors. Enjoy the opportunity to work with your car and take your time.
3. Begin at passenger side. Open the hook & loop tab.
4. Stretch out mirror cover tension cord and slip the cover over the mirror head. NOTE! Support the mirror head properly during installation by facing the vehicle door.
5. Form the mirror cover into place using both hands and temporarily fasten the hook and loop tab.
6. With both hands, continue forming the mirror cover into place (like molding clay). You may need to open/close hook & loop tab several times during this process. Adjust material around face of mirror until mirror-opening edges at tension cord align and meet.
7. Repeat Steps # 2 – 6 at driver side.

Final Adjustment

1. Adjust *SpeedLingerie™* where necessary, to assure proper fit.
2. For full effect of *SpeedLingerie™* design and glove-like fit, allow at least 72-hours for the materials to relax and conform to the curves of the vehicle.
3. Parking in a warm spot for a few days with *SpeedLingerie™* installed helps the process.
4. You may apply a quality vinyl conditioner to add shine and make it easier to wipe clean in the future. Spray the conditioner into the cloth and then apply to the Nose Cover. Do not soak the threads.

Care & Maintenance

1. For best results, vehicle surfaces must be washed and waxed, to ensure they are clean and dry before installing *SpeedLingerie™*.
2. Always inspect *SpeedLingerie™* fasteners and surfaces that contact vehicle for possible debris, sand, grit, etc and remove before installation (see step #7).
3. Periodically remove to allow complete aeration of vehicle paint finish and *SpeedLingerie™* materials.
4. Remove *SpeedLingerie™* before washing vehicle.
5. Remove *SpeedLingerie™* after exposure to rain or other fluids/moisture.
6. Clean outer vinyl surfaces of *SpeedLingerie™* with a high quality vinyl conditioner during routine car maintenance.
7. Clean felt inner surface with a shop vacuum (or shake it out) to remove any particles. If the inside it is *very* muddy or dirty, use low pressure fresh clean water to rinse it out and allow it to dry completely.
8. Rubber will stain vinyl. DO NOT store your *SpeedLingerie™* in direct contact with any rubber products (tires, hoses, etc) as vinyl is a very porous material and will absorb the black carbon in rubber products, resulting in a stain.

For installation questions call 650-964-2584 or email us at info@speedlingerie.com.

Congratulations on your purchase.